

Broil King®














Broil King
CROWN 520 SHADOW
8661-52
8661-53




Broil King
CROWN 590 SHADOW
8661-82
8661-83




HARDWARE INCLUDED

S21124		(2)	Y-29304		(2)
Y-12865		(12)	Y-11793		(4)
Y-11551		(2)	S21125		(2)
56039-214A		(1)	Y-12229		(1)
S21235		(2)	S21233		(2)
32001-151		(4)	S21088		(8)
					
20005-000					(1)


TOOLS REQUIRED





1





2




3






4




5

(2) 





6









(2) (1)





7

(2) 







9





10





11

(2)










12



(4)



13















16




(1)












20





KEY #	ITEM #	DESCRIPTION	8661-52	8661-53	8661-82	8661-83
1	52006-101	FIREBOX ASSEMBLY	1	1	1	1
2	56006-801	LID ASSEMBLY	1	1	1	1
7	Y-11544S	SCREW - BURNER	5	5	5	5
8	S21242	BURNER CLIP	5	5	5	5
18	52001-981	COOKING GRID	5	5	5	5
20	52006-991	GRID - WARMING RACK	1	1	1	1
21	59806-012	CONTROL ASSEMBLY	1	•	•	•
	59806-013	CONTROL ASSEMBLY	•	1	•	•
	59806-072	CONTROL ASSEMBLY	•	•	1	•
	59806-073	CONTROL ASSEMBLY	•	•	•	1
22	22026-903A	COLLECTOR BOX	1	1	1	1
24	10111-16A	CONNECTOR HOSE	1	1	1	1
25	52929-104D	BURNER	5	•	5	•
	52929-104E	BURNER	•	5	•	5
26	52002-291A	CONTROL KNOB	5	5	5	5
27	52001-291A	CONTROL KNOB	•	•	2	2
28	52026-1211CRO	CONTROL COVER	1	1	•	•
	52026-3011CRO	CONTROL COVER	•	•	1	1
31	52009-918	EDGE CAP - LH	1	1	1	1
32	52009-938	EDGE CAP - RH	1	1	1	1
34	Y-11230	COTTER PIN	•	•	1	1
37	53139-908	SHELF BRACKET SUPPORT	4	4	4	4
38	Y-12620	SHELF LOCK CLIP	4	4	4	4
41	10342-E13	ELECTRODE	1	1	1	1
42	10342-E22	ELECTRODE	1	1	1	1
43	10342-E38	ELECTRODE	1	1	1	1
44	10342-43	ELECTRONIC IGNITOR	1	1	•	•
	10342-45	ELECTRONIC IGNITOR	•	•	1	1
44A	25070-925	WIRE - IGNITOR	1	1	1	1
44B	25070-931	BUTTON - IGNITOR	1	1	1	1
49	51009-007	GREASE PAN	1	1	1	1
50	52060-1011	GREASE RAIL	1	1	1	1
51	52009-104	FLAV-R-WAVE ®	5	5	5	5
52	52149-004	GREASE SHIELD	4	4	4	4
56	24006-12A	HANDLE	1	1	1	1
58	24009-936	BEZEL	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1
60	10571-6	HEAT INDICATOR	1	1	1	1
62	53409-148	SHELF END CAP	2	2	2	2
65	20005-000	MATCH LIGHT - STICK	1	1	1	1
68	51276-2111A	DOOR	1	1	1	1
69	51276-2311A	DOOR	1	1	1	1
70	51476-138	HANDLE	2	2	2	2
78	56039-214A	MAGNET BRACKET	1	1	1	1
80	51189-1011A	SIDE PANEL	2	2	2	2
87	Y-11793	NUT 1/4-20	4	4	4	4
88	51386-2011	PANEL - REAR	1	1	1	1
90	51626-1311	BASE	1	1	1	1
99	32001-151	CASTOR BRACKET CAP	4	4	4	4
100	51639-108	CASTOR BRACKET	2	2	2	2
102	10892-286	CASTOR	4	4	4	4

KEY #	ITEM #	DESCRIPTION	8661-52	8661-53	8661-82	8661-83
103	21039-3011	TANK BRACKET	1	1	1	1
113	10342-T21	SIDE BURNER ELECTRODE	1	1	1	1
114	53109-1111	SHELF - RIGHT	1	1	1	1
115	53109-1111	SHELF - LEFT	1	1	•	•
	53109-1511	SHELF - SB - LEFT	•	•	1	1
123	Y-12117	BUSHING	•	•	2	2
124	53004-271	SIDE BURNER BODY	•	•	1	1
125	53000-2511	SIDE BURNER COVER	•	•	1	1
126	10390-E10D	SIDE BURNER	•	•	1	•
	10390-E10E	SIDE BURNER	•	•	•	1
128	53009-951	GRID	•	•	1	1
129	Y-11990	HEX NUT	•	•	1	1
130	27906-354	BURNER ROTISSERIE	•	•	1	1
133	S15278	ROTISSERIE HARDWARE	•	•	1	1
137	S15259	SPIT ROD	•	•	1	1
138	S15287	4 PRONG FORKS	•	•	2	2
139	20006-000	ROTISSERIE BRACKET	•	•	1	1
141	Y-11559	BOLT 1/4-20 X 1	2	2	2	2
142	S21125	SCREW #8 X 1/2	2	2	2	2
145	S21235	HINGE PIN	2	2	2	2
146	S21233	HITCH PIN CLIP	2	2	2	2
147	Y-11231	LID BUMPER	4	4	4	4
148	10240-20	DOOR PIN	2	2	2	2
149	Y-11551	SHOULDER SCREW 1/4-20 X 1	2	2	2	2
152	Y-12229	MAGNET	1	1	1	1
153	Y-12223	MAGNET - PUSH IN	2	2	2	2
154	Y-12132	WIRE CLIP	3	3	3	3
155	S21124	SCREW #8 X 1/2	4	4	4	4
157	Y-12835	SCREW #6-32 X 1/4	•	•	4	4
158	Y-12641	SCREW #8-32 X 1/2	•	•	2	2
159	S21127S	SCREW #8-32 X 7/16	10	10	14	14
160	Y-29304	SCREW #10-24 X 3/8	16	16	16	16
161	Y-12310	SCREW 1/4-20 X 3/4	8	8	8	8
162	S21088	SCREW #14 X 1/2	8	8	8	8
163	S21084	SCREW #14 X 3/8	4	4	4	4
169	S21061	WING NUT	•	•	2	2
171	S15246	MOTOR	•	•	1	1
172	S15508	ELECTRODE	•	•	1	1
173	S21362	SPRING	•	•	1	1
180	S35095	SCREW #10-24 X 5/8	•	•	2	2
186	Y-12865	SCREW 1/4-20 X 3/4	14	14	14	14

